




Greetings Distribution Partners and Installers:

The Main PCB of the APEX outdoor unit is shared with both the 2-3 Ton and 4-5 Ton capacity systems. When replacing this Main PCB, the blue jumper cap must be removed from the old board and installed on the new board. This will ensure that the correct capacity is assigned to the new replacement board. Failure to do so will result in system failure and errors.



As always, if you have any questions, please don't hesitate to contact our team.

The TOSOT BATHICA Support Group